



AUDIO RESOURCE GROUP PRIVACY MICROPHONE

Thanks for purchasing the Audio Resource Group MPH1 privacy microphone. Each set is packed with three silicone rubber gaskets to fit different mouth shapes, ten germ filters, ten sets cloth filters and one cable with a 6.5mm DC pin which plugs into the privacy microphone and a 3.5mm DC pin which plugs into our 72MHz wireless transmitter. It features crystal clear audio, being used for meetings or public gatherings of any kind to communicate with multiple language groups, to overcome background noise and distance from the individual speaker and in noisy or quiet environments. Every listener is assured a clear message with distraction.

a. Unpack the privacy microphone.



b. Choose the silicone rubber gasket that fits your mouth comfortably.



c. Insert the germ filter so that it covers all the base of the plastic filter.



d. Take out a piece of cloth filter pad and place it evenly onto the mouth piece, then push the center of the cloth filter onto the germ filter.



e. Plug the 6.5mm pin into the privacy microphone, and the other end into the mic-input jack of TalkandListen TLK-TX72BP wireless transmitter.



f. To replace the mic. PCB.

f.1 Remove the mouth guard.



f.2 Press the centre of the flexible plastic filter and lift it out



f.3 Lift out the connector wire and use a screwdriver to take out the screw.



f.4 Take out the PCB and replace with a new one

